



VeloFlex Screw-In Bollards Installation Details

1. Drill hole 130mm deep and 30mm in diameter
2. Vacuum outside and inside the Hole to remove all dust & debris
3. Apply epoxy glue and Fill Hole 60%
4. Insert & press the Bollard into the hole with the metal anchor already in place/affixed to bottom of the bollard (see page 2)



Attaching Metal Anchor to Base of VeloFlex Bollard

