

INSTALLATION INSTRUCTIONS FOR SCHOOL PENCIL BOLLARDS & VELOFLEX BOLLARDS

1. Drill hole 130mm deep and 30mm in diameter
2. Vacuum/remove fully all debris inside the hole
3. Apply Epoxy resin and fill the hole 60%
4. Insert and press the bollard down into the hole with the metal anchor already in place/affixed to the bottom of the bollard (see photo 6 below)
5. Ensure bottom of the bollard is sitting flush on the road/pavement surface and is straight.

